

# Bixolon printing double-spaced, extra blank lines

## Summary:

Bixolon printing double-spaced, extra blank lines

When printing a receipt using a Bixolon SRP350PlusII, there is a blank space in between every printed line.

## Cause:

DIP switches are set incorrectly on the printer. To view the current settings of the DIP switches, hold down the FEED button while powering on the printer.

## Solution:

To change the DIP switch settings on the Bixolon printer:

- Power the printer off.
- Unplug the power cable from the back of the printer.
- Using a standard screw driver, remove the plate on the bottom of the printer.

The DIP switch settings should be as follows:

**Bank 1:** 1-5 OFF; 6-8 ON

**Bank 2:** All OFF

Online URL: <https://counterpoint.knowledgebase.co/article.php?id=375>