

Enable / Disable the 'Show Card to Cashier' message on the Payment Terminal

Summary:

How to disable the 'Show Card to Cashier' message on the Payment Terminal (isc250 / i6550).

Enable / Disable the customer prompt to 'Show Card to Cashier'

Solution:

As of 8.4.6.6, this message is controlled by the 'Prompt for Last 4 Digits' selection in the device setup.

In Setup / Point of Sale / **Devices** - uncheck the '**Prompt for Last 4 Digits**' box to disable the prompt on the Ingenico device.

Online URL: <https://counterpoint.knowledgebase.co/article.php?id=321>