CPMobile: How to restore Linea Pro sled to default settings

Summary:

How to restore LineaPro sled to default settings

Resetting the Linea Pro sled to its default configuration

Cause:

The Linea Pro sled was reprogrammed using scan sheets and no longer scans barcodes as expected.

Solution:

To restore the sled to its factory settings, press and hold the **battery** button and the **scan** button, at the same time, until the sled beeps.

Online URL: https://counterpoint.knowledgebase.co/article.php?id=798